

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS210 TOY 2WD 79-83 BALL JOINT SPACERS
INCL: 2 SPACERS, 2 UPPER PLATES, 8 BLTS, 8
NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED
BETWEEN THE UPPER CONTROL ARM (UCA) &
THE UPPER BALL JOINT (UBJ). AFTER
REMOVING THE BOLTS SECURING THE UBJ
TO THE UCA, PLACE THE SPACER IN
BETWEEN THE BOTTOM SURFACE OF THE
UCA & THE UPPER SURFACE OF THE UBJ. THE
SPACER PLATE SHOULD SIT ON THE TOP OF
THE UPPER CONTROL ARM. INSERT THE
BOLTS FROM THE TOP DOWN, THROUGH THE
UPPER PLATE, THEN THE CONTROL ARM
THROUGH THE BALL JOINT, WITH THE NUTS
& WASHERS ON THE BOTTOM OF THE BALL
JOINTS.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS210 TOY 2WD 79-83 BALL JOINT SPACERS
INCL: 2 SPACERS, 2 UPPER PLATES, 8 BLTS, 8
NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED
BETWEEN THE UPPER CONTROL ARM (UCA) &
THE UPPER BALL JOINT (UBJ). AFTER
REMOVING THE BOLTS SECURING THE UBJ
TO THE UCA, PLACE THE SPACER IN
BETWEEN THE BOTTOM SURFACE OF THE
UCA & THE UPPER SURFACE OF THE UBJ. THE
SPACER PLATE SHOULD SIT ON THE TOP OF
THE UPPER CONTROL ARM. INSERT THE
BOLTS FROM THE TOP DOWN, THROUGH THE
UPPER PLATE, THEN THE CONTROL ARM
THROUGH THE BALL JOINT, WITH THE NUTS
& WASHERS ON THE BOTTOM OF THE BALL
JOINTS.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS210 TOY 2WD 79-83 BALL JOINT SPACERS
INCL: 2 SPACERS, 2 UPPER PLATES, 8 BLTS, 8
NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED
BETWEEN THE UPPER CONTROL ARM (UCA) &
THE UPPER BALL JOINT (UBJ). AFTER
REMOVING THE BOLTS SECURING THE UBJ
TO THE UCA, PLACE THE SPACER IN
BETWEEN THE BOTTOM SURFACE OF THE
UCA & THE UPPER SURFACE OF THE UBJ. THE
SPACER PLATE SHOULD SIT ON THE TOP OF
THE UPPER CONTROL ARM. INSERT THE
BOLTS FROM THE TOP DOWN, THROUGH THE
UPPER PLATE, THEN THE CONTROL ARM
THROUGH THE BALL JOINT, WITH THE NUTS
& WASHERS ON THE BOTTOM OF THE BALL
JOINTS.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS210 TOY 2WD 79-83 BALL JOINT SPACERS
INCL: 2 SPACERS, 2 UPPER PLATES, 8 BLTS, 8
NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED
BETWEEN THE UPPER CONTROL ARM (UCA) &
THE UPPER BALL JOINT (UBJ). AFTER
REMOVING THE BOLTS SECURING THE UBJ
TO THE UCA, PLACE THE SPACER IN
BETWEEN THE BOTTOM SURFACE OF THE
UCA & THE UPPER SURFACE OF THE UBJ. THE
SPACER PLATE SHOULD SIT ON THE TOP OF
THE UPPER CONTROL ARM. INSERT THE
BOLTS FROM THE TOP DOWN, THROUGH THE
UPPER PLATE, THEN THE CONTROL ARM
THROUGH THE BALL JOINT, WITH THE NUTS
& WASHERS ON THE BOTTOM OF THE BALL
JOINTS.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800