

**FABTECH MOTORSPORTS**

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS211 TOY 2WD 84-95 BALL JOINT SPACERS  
INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED BETWEEN THE UPPER CONTROL ARM (UCA) & THE UPPER BALL JOINT (UBJ). AFTER REMOVING THE BOLTS SECURING THE UBJ TO THE UCA, PLACE THE SPACER IN BETWEEN THE BOTTOM SURFACE OF THE UCA & THE UPPER SURFACE OF THE UBJ. INSERT THE BOLTS FROM THE TOP DOWN WITH THE NUTS & WASHERS ON THE BOTTOM OF THE BALL JOINTS.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800

**FABTECH MOTORSPORTS**

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS211 TOY 2WD 84-95 BALL JOINT SPACERS  
INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED BETWEEN THE UPPER CONTROL ARM (UCA) & THE UPPER BALL JOINT (UBJ). AFTER REMOVING THE BOLTS SECURING THE UBJ TO THE UCA, PLACE THE SPACER IN BETWEEN THE BOTTOM SURFACE OF THE UCA & THE UPPER SURFACE OF THE UBJ. INSERT THE BOLTS FROM THE TOP DOWN WITH THE NUTS & WASHERS ON THE BOTTOM OF THE BALL JOINTS.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800

**FABTECH MOTORSPORTS**

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS211 TOY 2WD 84-95 BALL JOINT SPACERS  
INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED BETWEEN THE UPPER CONTROL ARM (UCA) & THE UPPER BALL JOINT (UBJ). AFTER REMOVING THE BOLTS SECURING THE UBJ TO THE UCA, PLACE THE SPACER IN BETWEEN THE BOTTOM SURFACE OF THE UCA & THE UPPER SURFACE OF THE UBJ. INSERT THE BOLTS FROM THE TOP DOWN WITH THE NUTS & WASHERS ON THE BOTTOM OF THE BALL JOINTS.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800

**FABTECH MOTORSPORTS**

4331 EUCALYPTUS AVE. CHINO, CA. 91710

FTS211 TOY 2WD 84-95 BALL JOINT SPACERS  
INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED BETWEEN THE UPPER CONTROL ARM (UCA) & THE UPPER BALL JOINT (UBJ). AFTER REMOVING THE BOLTS SECURING THE UBJ TO THE UCA, PLACE THE SPACER IN BETWEEN THE BOTTOM SURFACE OF THE UCA & THE UPPER SURFACE OF THE UBJ. INSERT THE BOLTS FROM THE TOP DOWN WITH THE NUTS & WASHERS ON THE BOTTOM OF THE BALL JOINTS.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800