

FABTECH MOTORSPORTS
4331 EUCALYPTUS AVE
CHINO, CA. 91710
909-597-7800 FAX 909-597-7185

**1984-95 TOYOTA 2 WHEEL DRIVE
LONG TRAVEL STRUT FRAME KIT
FTS4130-9, FTS4130-10**

Disconnect the negative terminal on the battery.

PARTS LIST:

1 EA. STRUT FRAME
1 EA. STRUT ARM RIGHT
1 EA. STRUT ARM LEFT
2 EA. ½" X 3" GRADE 8 BOLTS
2 EA. ½" C-LOCK NUTS
2 EA. ¾" HEIM JOINTS
4 EA. HEIM SPACERS
2 EA. ½" X 1 ¼" GRADE 5 BOLTS
2 EA. ½" NUTS
4 EA. ½" FLAT WASHERS
4 EA. ½" LOCK WASHERS
2 EA. RIGHT JAM NUTS

FABTECH MOTORSPORTS
4331 EUCALYPTUS AVE.
CHINO, CA. 91710
909-597-7800 FAX 909-597-7185

**1984-95 TOYOTA 2 WHEEL DRIVE
LONG TRAVEL STRUT FRAME KIT
FTS4130-9, FTS4130-10**

Disconnect the negative terminal on the battery.

PARTS LIST:

1 EA. STRUT FRAME
1 EA. STRUT ARM RIGHT
1 EA. STRUT ARM LEFT
2 EA. ½" X 3" GRADE 8 BOLTS
2 EA. ½" C-LOCK NUTS
2 EA. ¾" HEIM JOINTS
4 EA. HEIM SPACERS
2 EA. ½" X 1 ¼" GRADE 5 BOLTS
2 EA. ½" NUTS
4 EA. ½" FLAT WASHERS
4 EA. ½" LOCK WASHERS
2 EA. RIGHT JAM NUTS

FABTECH MOTORSPORTS
4331 EUCALYPTUS AVE
CHINO, CA. 91710
909-597-7800 FAX 909-597-7185

**1984-95 TOYOTA 2 WHEEL DRIVE
LONG TRAVEL STRUT FRAME KIT
FTS4130-9, FTS4130-10**

Disconnect the negative terminal on the battery.

PARTS LIST:

1 EA. STRUT FRAME
1 EA. STRUT ARM RIGHT
1 EA. STRUT ARM LEFT
2 EA. ½" X 3" GRADE 8 BOLTS
2 EA. ½" C-LOCK NUTS
2 EA. ¾" HEIM JOINTS
4 EA. HEIM SPACERS
2 EA. ½" X 1 ¼" GRADE 5 BOLTS
2 EA. ½" NUTS
4 EA. ½" FLAT WASHERS
4 EA. ½" LOCK WASHERS
2 EA. RIGHT JAM NUTS

FABTECH MOTORSPORTS
4331 EUCALYPTUS AVE
CHINO, CA. 91710
909-597-7800 FAX 909-597-7185

**1984-95 TOYOTA 2 WHEEL DRIVE
LONG TRAVEL STRUT FRAME KIT
FTS4130-9, FTS4130-10**

Disconnect the negative terminal on the battery.

PARTS LIST:

1 EA. STRUT FRAME
1 EA. STRUT ARM RIGHT
1 EA. STRUT ARM LEFT
2 EA. ½" X 3" GRADE 8 BOLTS
2 EA. ½" C-LOCK NUTS
2 EA. ¾" HEIM JOINTS
4 EA. HEIM SPACERS
2 EA. ½" X 1 ¼" GRADE 5 BOLTS
2 EA. ½" NUTS
4 EA. ½" FLAT WASHERS
4 EA. ½" LOCK WASHERS
2 EA. RIGHT JAM NUTS