

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

Disconnect the negative terminal on the battery.

FTS510 CHEVY S10 BALL JOINT SPACERS

INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED BETWEEN THE UPPER CONTROL ARM (UCA) & THE UPPER BALL JOINT (UBJ). AFTER REMOVING THE RIVETS SECURING THE UBJ TO TO THE UCA, PLACE THE UBJ BELOW THE UCA, WITH THE SPACER SEPARATING THE BOTTOM SURFACE OF THE UCA FROM THE TOP SURFACE OF THE UBJ. INSERT THE BOLTS FROM THE BOTTOM UP WITH THE NUTS & WASHERS ON TOP OF THE UCA.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

Disconnect the negative terminal on the battery.

FTS510 CHEVY S10 BALL JOINT SPACERS

INCL: 2 SPACERS, 8 BLTS, 8 NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED BETWEEN THE UPPER CONTROL ARM (UCA) & THE UPPER BALL JOINT (UBJ). AFTER REMOVING THE RIVETS SECURING THE UBJ TO TO THE UCA, PLACE THE UBJ BELOW THE UCA, WITH THE SPACER SEPARATING THE BOTTOM SURFACE OF THE UCA FROM THE TOP SURFACE OF THE UBJ. INSERT THE BOLTS FROM THE BOTTOM UP WITH THE NUTS & WASHERS ON TOP OF THE UCA.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

Disconnect the negative terminal on the battery.

FTS510 CHEVY S10 BALL JOINT SPACERS

INCL: 2 SPACERS, 8 BOLTS, 8 NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED BETWEEN THE UPPER CONTROL ARM (UCA) & THE UPPER BALL JOINT (UBJ). AFTER REMOVING THE RIVETS SECURING THE UBJ TO TO THE UCA, PLACE THE UBJ BELOW THE UCA, WITH THE SPACER SEPARATING THE BOTTOM SURFACE OF THE UCA FROM THE TOP SURFACE OF THE UBJ. INSERT THE BOLTS FROM THE BOTTOM UP WITH THE NUTS & WASHERS ON TOP OF THE UCA.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800-FABTECH

FABTECH MOTORSPORTS

4331 EUCALYPTUS AVE. CHINO, CA. 91710

Disconnect the negative terminal on the battery.

FTS510 CHEVY S10 BALL JOINT SPACERS

INCL: 2 SPACERS, 8 BOLTS, 8 NUTS, 8 WASHERS

THE BALL JOINT SPACER IS TO BE INSTALLED BETWEEN THE UPPER CONTROL ARM (UCA) & THE UPPER BALL JOINT (UBJ). AFTER REMOVING THE RIVETS SECURING THE UBJ TO TO THE UCA, PLACE THE UBJ BELOW THE UCA, WITH THE SPACER SEPARATING THE BOTTOM SURFACE OF THE UCA FROM THE TOP SURFACE OF THE UBJ. INSERT THE BOLTS FROM THE BOTTOM UP WITH THE NUTS & WASHERS ON TOP OF THE UCA.

FOR TECHNICAL ASSISTANCE CALL:

909-597-7800-FABTECH