

## **FABTECH MOTORSPORTS**

4331 EUCALYPTUS AVE. CHINO, CA. 91710  
909-597-7800

FTS710 NISSAN BALL JOINT SPACERS  
INCL: 2 SPACERS, 8 BLTS, 8 WASHERS,  
8 LOCK WASHERS

Disconnect the negative terminal on the battery.  
THE BALL JOINT SPACER IS TO BE  
INSTALLED BETWEEN THE UPPER CONTROL  
ARM (UCA) & THE UPPER BALL JOINT (UBJ).  
AFTER REMOVING THE BOLTS SECURING  
THE UBJ TO THE UCA, PLACE THE SPACER IN  
BETWEEN THE UBJ AND THE UCA. SLIDE A  
LOCK WASHER FOLLOWED BY A FLAT  
WASHER ONTO EACH BOLT AND APPLY A  
SMALL AMOUNT OF THREAD LOCKING  
COMPOUND TO THE THREADS. INSERT THE  
BOLTS THROUGH THE UCA AND HAND  
TIGHTEN. AFTER ALL BOLTS ARE IN  
POSITION, FULLY TORQUE ALL FOUR BOLTS.

## **FABTECH MOTORSPORTS**

4331 EUCALYPTUS AVE. CHINO, CA. 91710  
909-597-7800

FTS710 NISSAN BALL JOINT SPACERS  
INCL: 2 SPACERS, 8 BLTS, 8 WASHERS,  
8 LOCK WASHERS

Disconnect the negative terminal on the battery.  
THE BALL JOINT SPACER IS TO BE  
INSTALLED BETWEEN THE UPPER CONTROL  
ARM (UCA) & THE UPPER BALL JOINT (UBJ).  
AFTER REMOVING THE BOLTS SECURING  
THE UBJ TO THE UCA, PLACE THE SPACER IN  
BETWEEN THE UBJ AND THE UCA. SLIDE A  
LOCK WASHER FOLLOWED BY A FLAT  
WASHER ONTO EACH BOLT AND APPLY A  
SMALL AMOUNT OF THREAD LOCKING  
COMPOUND TO THE THREADS. INSERT THE  
BOLTS THROUGH THE UCA AND HAND  
TIGHTEN. AFTER ALL BOLTS ARE IN  
POSITION, FULLY TORQUE ALL FOUR BOLTS.

## **FABTECH MOTORSPORTS**

4331 EUCALYPTUS AVE. CHINO, CA. 91710  
909-597-7800

FTS710 NISSAN BALL JOINT SPACERS  
INCL: 2 SPACERS, 8 BLTS, 8 WASHERS,  
8 LOCK WASHERS

Disconnect the negative terminal on the battery.  
THE BALL JOINT SPACER IS TO BE  
INSTALLED BETWEEN THE UPPER CONTROL  
ARM (UCA) & THE UPPER BALL JOINT (UBJ).  
AFTER REMOVING THE BOLTS SECURING  
THE UBJ TO THE UCA, PLACE THE SPACER IN  
BETWEEN THE UBJ AND THE UCA. SLIDE A  
LOCK WASHER FOLLOWED BY A FLAT  
WASHER ONTO EACH BOLT AND APPLY A  
SMALL AMOUNT OF THREAD LOCKING  
COMPOUND TO THE THREADS. INSERT THE  
BOLTS THROUGH THE UCA AND HAND  
TIGHTEN. AFTER ALL BOLTS ARE IN  
POSITION, FULLY TORQUE ALL FOUR BOLTS.

## **FABTECH MOTORSPORTS**

4331 EUCALYPTUS AVE. CHINO, CA. 91710  
909-597-7800

FTS710 NISSAN BALL JOINT SPACERS  
INCL: 2 SPACERS, 8 BLTS, 8 WASHERS,  
8 LOCK WASHERS

Disconnect the negative terminal on the battery.  
THE BALL JOINT SPACER IS TO BE  
INSTALLED BETWEEN THE UPPER CONTROL  
ARM (UCA) & THE UPPER BALL JOINT (UBJ).  
AFTER REMOVING THE BOLTS SECURING  
THE UBJ TO THE UCA, PLACE THE SPACER IN  
BETWEEN THE UBJ AND THE UCA. SLIDE A  
LOCK WASHER FOLLOWED BY A FLAT  
WASHER ONTO EACH BOLT AND APPLY A  
SMALL AMOUNT OF THREAD LOCKING  
COMPOUND TO THE THREADS. INSERT THE  
BOLTS THROUGH THE UCA AND HAND  
TIGHTEN. AFTER ALL BOLTS ARE IN  
POSITION, FULLY TORQUE ALL FOUR BOLTS.