

4331 EUCALYPTUS AVE. ~~ CHINO, CA 91710 909-597-7800 Fax 909-597-7185 FTR10006

RHINO HEAVY DUTY STEERING KIT

(for use with Fabtech Long Travel Suspension System)

PARTS LIST:

	FTR10006	Rhino Heim Steering Kit
Qty	Part #	Description
2	FT95018GR	Heavy Duty Adjuster Sleeve
1	FT95062	Hardware Kit
1	FT95200	Hdwr Sub-Assembly Kit

	FT95200	Hdwr Sub-Assembly Kit
Qty	Part #	Description
4	06001007000	Cotter Pin 1/16" X 1"
2	12001407100	14" Zip Tie
2	FT10006i	Instruction Sheet
2	FT95011	Steering Arm Hat HD
4	FT95017	Low Pro Mis-Alignment
1	FT95025	Inner Tie Rod Bracket Drv
1	FT95026	Inner Tie Rod Bracket Pass
4	FTS43	Mis-Alignment
2	FTS98003	3/4" Heim LH
2	FTS98009	3/4" Heim RH
1	FTAS12	Fabtech Sticker
1	FTAS16	Driver Warning
1	FTREGCARD	Reg. Card

HARDWARE LIST:

Qty	Description	Location
2	1/2"-20 x 3 1/2" Hex Cap Bolt	Outer Tie Rod (Heim Joint)
2	1/2"-20 x 2 1/4" Hex Cap Bolt	Inner Tie Rod (Heim Joint)
4	1/2"-20 C-Lock Nut	
6	1/2" SAE Flat Washer	
2	3/4"-16 Jam Nut (right hand thread)	
2	3/4"-16 Jam Nut (left hand thread)	
2	12mm x 1.25 x 20mm Bolt	Clevis Hardware
1	FTLock	Thread-locking Compound

TOOL LIST:

- o Assorted Metric & Standard Wrenches
- o Torque Wrench
- o Floor Jack
- o Jack Stands



4331 EUCALYPTUS AVE. ~~ CHINO, CA 91710 909-597-7800 Fax 909-597-7185 FTR10006 RHINO HEAVY DUTY STEERING KIT

WARNING

THIS HEAVY DUTY STEERING KIT IS DESIGNED TO WORK WITH FABTECH'S RHINO LONG TRAVEL SUSPENSION SYSTEM. THIS KIT WILL NOT WORK WITH A STOCK TYPE SUSPENSION

READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION.

CHECK ALL PARTS INCLUDED IN THIS KIT TO THE PARTS LIST ABOVE BEFORE BEGINNING INSTALLATION OF THIS KIT. IF ANY PARTS ARE MISSING, CONTACT FABTECH AT 909-597-7800.

DO NOT ALTER THE FINISH OF THESE COMPONENTS, EXAMPLE- CHROMING, ZINC PLATING OR PAINTING. CHANGING THE FINISH CAN CAUSE STRUCTURAL FATIGUE OF COMPONENTS.

INSTALLATION INSTRUCTIONS:


Disconnect the negative terminal on the battery. Center
the steering wheel, rack & pinion, and wheels and
tires. Jack up the front end of the truck and support the
frame rails with jack stands. NEVER WORK UNDER
AN UNSUPPORTED VEHICLE. Remove the front
wheels and tires.

IF YOU ARE INSTALLING THIS HEAVY DUTY STEERING KIT IN CONJUNCTION WITH THE LONG TRAVEL SUSPENSION KIT, REFER TO THE INSTRUCTIONS INCLUDED WITH THAT SYSTEM FOR THE MODIFICATIONS REQUIRED (DRILLING) TO THE FACTORY STEERING KNUCKLE AND OUTER TIE ROD END REMOVAL. THEN PROCEED TO STEP # 2


2. Working from the drivers side of the Rhino, disconnect the ½" heim and the hardware from the steering knuckle. Remove the 3/8" diameter steering hat from the knuckle. Cut the factory inner Tie Rod Boot Clamp from the boot (DO NOT CUT OR DAMAGE BOOT). Pull the boot outward toward the steering knuckle to gain access to the wrench flat on the inner tie rod. Remove the tie rod assembly from the rack & Pinion. Carefully remove the boot from the tie rod assembly and discard the rest of the tie rod assembly. SEE

PHOTOS IN NEXT COLUMN AND ON NEXT PAGE.







 Locate FT95025 Driver Inner Tie Rod Bracket and the supplied 12mm bolt and thread-locking compound. Position the bracket to the rack & pinion and attach with the 12mm hardware. Use some of the supplied thread-locking compound and torque to 75 lbs. SEE PHOTOS BELOW.






- 4. Locate the factory inner tie rod boot and FT95018GR Heavy Duty Adjuster Sleeve. Install the boot onto the adjuster sleeve so that it is in the same position that it was removed from the factory tie rod assembly. (the end of the adjuster sleeve with the wrench flats need to be out at the knuckle).
- 5. Locate a FTS98003 ¾" Right Hand Heim, FTS98009 ¾" Left Hand Heim, and a supplied right and left hand jam nut from the hardware kit. Use some anti-seize compound on the heims and thread the jam nuts half way onto the appropriate heim. Thread the heim into the adjuster sleeve.
- 6. Locate FT 95017 Low Profile Mis-alignments and the supplied ½" x 2 ¼" hardware. Insert the mis-alignments into the left hand thread heim and attach the to the tie rod bracket with the head of the bolt toward the front of the Rhino (use a ½" flat washer on both outer sides of the tie rod bracket). Torque to 75 lbs. SEE PHOTOS BELOW.







7. Locate FT95011 Heavy Duty Steering Arm Hat and install into the steering knuckle where the 3/8" diameter


one was previously removed. Locate FTS43 Misalignments and the supplied ½" x 3 ½" hardware. Install the misalignments into the right hand thread heim and place on top of the steering hat. Inset the ½" bolt from the top of the heim and down into the knuckle. Place one ½" washer on the bottom of the knuckle with a C-Lock nut. Torque to 75 lbs. SEE PHOTOS BELOW AND IN NEXT COLUMN.








- 8. Repeat steps two through six on the passenger side of the Rhino.
- 9. Install the wheels and tires and remove the jack stands. Move the Rhino 10 feet backward and forward a couple of times. (DO NOT DRIVE THE RHINO WITH THE STEERING COMPONETS LOOSE). Check the toe setting on the Rhino and adjust as necessary. Tighten the jam nuts on the heims. Re-torque after 100 miles Make sure that the rack & pinion is centered before adjusting the inner and outer tie rods, and that both sides are adjusted equally for proper thread engagement on all the ends. This will ensure the correct amount of turns in the steering to both sides.
- 10. Once the toe set has been made, pull the boot over the clevis and position it back onto the rack & pinion where it was factory on the rack & pinion. Secure the boot to the rack using the supplied 14" zip tie. SEE PHOTOS ON NEXT PAGE.





RETORQUE ALL NUTS, BOLTS AND LUGS AFTER 50 MILES AND PERIODICALLY THEREAFTER. For technical assistance call: 909-597-7800

Product Warranty and Warnings-

Fabtech provides a Limited Lifetime Warranty to the original retail purchaser who owns the vehicle, on which the product was originally installed, for defects in workmanship and materials.

The Limited Lifetime Warranty excludes the following Fabtech items; bushings, bump stops, ball joints, tie rod ends, limiting straps, cross shafts, heim joints. These parts are subject to wear and are not considered defective when worn. They are warranted for 60 days from the date of purchase for defects in workmanship.

Take apart shocks are considered a serviceable shock with a one year warranty on leakage only. Service seal kits are available separately for future maintenance. All other shocks are covered under our Limited Lifetime Warranty.

Fabtech does not warrant any product for finish, alterations, modifications and/or installation contrary to Fabtech's instructions. Alterations to the finish of the parts including but not limited to painting, powdercoating, plating and/or welding will void all warranties. Some finish damage may occur to parts during shipping which is considered normal and is not covered under warranty.

Fabtech products are not designed nor intended to be installed on vehicles used in race applications or for racing purposes or for similar activities. (A "RACE" is defined as any contest between two or more vehicles, or any contest of one or more vehicle against the clock, whether or not such contest is for a prize). This warranty does not include coverage for police or taxi vehicles, race vehicles, or vehicles used for government or commercial purposes. Also excluded from this warranty are sales outside of the United States of America.

Installation of most suspension products will raise the center of gravity of the vehicle and will cause the vehicle to handle differently than stock. It may increase the vehicle's susceptibility to a rollover, on road and off road, at all speeds. Extreme care should be taken to operate the vehicle safely at all times to prevent rollover or loss of control resulting in serious injury or death. Fabtech front end Desert Guards may impair the deployment or operation of vehicles equipped with supplemental restraining systems/air bag systems and should not be installed if the vehicle is equipped as so.

Fabtech makes every effort to ensure suspension product compatibility with all vehicles listed in the catalog, but due to unknown auto manufacturers production changes and/or inconstancies by the auto manufacturer, Fabtech cannot be responsible for 100% compatibility, including the fitment of tire and wheel sizes listed. The Tire and Wheel sizes listed in Fabtech's catalog are only a guideline for street driving with noted fender trimming. Fabtech is not responsible for damages to the vehicle's body or tires.

Fabtech's obligation under this warranty is limited to the repair or replacement, at Fabtech option, of the defective product only. All costs of removal, installation or re-installation, freight charges, incidental or consequential damages are expressly excluded from this warranty. Fabtech is not responsible for damages and/or warranty of other vehicle parts related or non related to the installed Fabtech product. This warranty is expressly in lieu of all other warranties expressed or implied. This warranty shall not apply to any product that has been subject to accident, negligence, alteration, abuse or misuse as determined by Fabtech.

Fabtech suspension components must be installed as a complete system including shocks as shown in our current catalog. All warranties will become void if Fabtech parts are combined and/or substituted with other aftermarket suspension products. Combination and/or substitution of other aftermarket suspension parts may cause premature wear and/or product failure resulting in an accident causing injury or death. Fabtech does not warrant products not manufactured by Fabtech.

Installation of Fabtech product may void the vehicles factory warranty; it is the consumer's responsibility to check with their local vehicle's dealer for warranty disposition before the installation of the product.

It is the responsibility of the distributor and/or the retailer to review all warranties and warnings of Fabtech products with the consumer prior to purchase.

Fabtech reserves the right to supercede, discontinue, change the design, finish, part number and, or application of parts when deemed necessary without written notice. Fabtech is not responsible for misprints or typographical errors within the catalog or price sheet.

Instruction Sheet Part #- FTR10006i

2/25/13 GS